

Instructions

- 1) Turn on the power switch located at the bottom of the candle.
- 2) Press the “ON” / “OFF” button to turn the candle light ON/OFF.
- 3) There are two modes for the candle light, flickering light or steady light. Press the “ Mode” button to set your (flickering or steady) light.
- 4) When the candle light is on, press the “4H”/“8H” button to set the candle burning time for 4/8 hours. Once the time is set, the candle light will automatically turn off after 4/8 hours.
- 5) Press the “Multi Color” button to let the candle light change colors automatically; press the button again to stay at the current color.
- 6) Color keys: Simply press one of the twelve color keys to set your favorite color.

