

Instruction:

Use with the Remote Control

Turn on the power switch first. Press “ON”/ “OFF” button to turn the candle on/off.

Mode-There are two modes for the candle light, Press “Candle” to get flickering light and press “Light” to get steady light.

Timer-when the candle light is on, press “4H”/“8H” to set the candle “burning” time for 4/8hours.Once the time is set, the candle light automatically turns off after 4/8 hours.

Dimmer-Use these two dimmer buttons to change the brightness of the candle.

